

INSTRUCTIONS:

The eyelet bolt of the Fantasy Swing® can be installed in two places: into the underside wooden frame of a doorway, or into a beam in the ceiling. Installing the eyelet bolt into a doorframe is easiest, but the doorway limits your range of motion. Installing the eyelet bolt into a strong ceiling beam is the preferred method of use. Please follow both sets of instructions carefully to ensure a safe and enjoyable Fantasy Swing,® experience.

FOR DOORWAYS: Locate the center of the wooden doorway and mark a spot on the underside of the doorframe. The eyelet bolt is very sharp and can be screwed in by tapping the head of the bolt with a hammer and twisting the screw until all of the threads are concealed. Use the hammer claw to help turn the eyelet bolt into the wood. To facilitate insertion, drill a 5/16 pilot hole first, then screw the eyelet bolt in. All of the threads should be concealed.

FOR CEILINGS: Locate a beam in your ceiling using a stud finder, available from any hardware store. Make sure you have enough clearance from any surrounding walls or furniture. Find the center of the beam and mark a spot. The eyelet bolt is very sharp and can be screwed in by tapping the head of the bolt with a hammer and twisting the screw until all of the threads are concealed. Use the hammer claw to help turn the eyelet screw into the wood. To facilitate insertion, drill a 5/16 pilot hole first, then screw the eyelet bolt in. All of the threads should be concealed.

CAUTION:*Once the eyelet bolt is installed, do not remove it for safety purposes. Doing so could weaken the eyelet bolt hold!*

HANGING THE SWING: If the weight on the swing is less than 200 lbs., use the Torsion Spring provided. If the weight on the swing is over 200 lbs., assemble the swing hardware without the use of a spring. During two-person usage, make sure to account for the position of both partners when determining the weight (one partner may be on the floor, not actually hanging from the spring).

WARNING:*If using Torsion Spring, avoid putting hands on or near spring while using the Fantasy Swing®. Your fingers or other body parts may get pinched if too close!* The Fantasy Swing® is fully adjustable and designed for your comfort. All pads, supports, and stirrups can be adjusted to accommodate a variety of sexual positions with minimal exertion. The hardware for the swing can also be adjusted to hang the swing any distance from the floor. Use your imagination and have fun!

WARNING:*Suggested weight limit not to exceed 350 lbs. Install and use at your own risk.*